


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


CABINET PARTS

Illus	. Part		Illus	. Part		Illus	. Part	
No.		DESCRIPTION	No.	No.	DESCRIPTION	No.		DESCRIPTION
			13		Hinge Bottom	25	489084	Screw
1	W/40400740	Literature Parts		W10138965		26		Door Closer
		Energy Guide		2303141			2155311	RC
		Owner's Manual	14		Filler, Wrapper		2223751	
	W10142162	Service & Wiring	' '	2304846		27	489483	_
	0000407	Sheet		2304849		28	2260507	
	2220407			2304848				Filter
	0040004	Service Sheet			Apollo Grey	29	4396841	
	2216001		15		Grille	30		Cap, Water
		(Door Removal)		2323580W	White			Filter
				2323580T			2260502W	
_	4000774	F (0)		2323580B			2260502T	Biscuit
2		Front Roller (2)			Midnight Grey		2260502B	
3	3400517		16	489497	Screw			Midnight Grey
4		Rear Roller (2)	17	489464		31	489500	
5	489427	=	18		Drain Fitting	32	2260519	=
6		Clip, Grille	19		Extension Tube			Support
7	489478		20	1108439		33		Button, Water
8	2156056		21	2188755	Cover, Unit			Filter
9	2203771	Hinge Top (RC)	22		Cabinet (Not A		2260503W	White
10	3400113				Serviceable Part)		2260503T	Biscuit
11	8281227	=	23		Hinge Cover (RC)		2260503B	
12	W40400570	Hinge Cover (FC)		W10138581	White			Midnight Grey
	W10138576			W10138583	Biscuit	34		Tube, Filter
	W10138578			W10138582			30.00	Outlet
	W10138577				Apollo Grey	35	2319867	
	W10138579	Apollo Grey	24		Clamp, Service			Inlet
					Cord	36	2203770	Hinge Top (FC)


REFRIGERATOR LINER PARTS



REFRIGERATOR SHELF PARTS



s. Part	
No.	DESCRIPTION
	Stud Assembly
2196483	Stud Assembly
2179259	Glass, Meat Cover
2174150	Glass, Cover
2311726	Cover, Meat Pan
8281158	
2188652	Crisper Pan
2179343	Body, Humidity
	Control
2179342	Slide, Humidity
	Control
2255593	Trim, Handle
2188654	Meat Pan
2179350	Deflector
2255592	Trim, Handle
W10141750	Shelf, Snack Bin
2179243	Trim, Handle
W10141749	Shelf Assembly,
	Spillguard (2)
	No. 2196485 2188655 2209698 3400894 2196483 2179259 2174150 2311726 8281158 2188652 2179343 2179342 2255593 2188654 2179350 2255592 W10141750 2179243




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A
		Seviceable Part)
2	2211746K	Shelf, Slide Out
_		Upper
3	0004004	Track, Basket-Dual
	2301291	Right
4	2301292	Left
4	2211742K	Shelf, Slide Out
5	2182971	Freezer Bin
6 7	3400893	Screw
/	2201200	Shelf Track
	2301289	Right Side Left Side
8	2301290 2205837K	Shelf (2)
9	W10004810	Screw (8)
10	842534	Clip, Air Duct (2)
11	2198587	Cover, Emitter
12	2198635	Spring
13	2198634	Pin
14	1115373	Switch, Rocker Arm
15	2220398	P.C. Board
		Emitter
16	2255588	Cover, Ice Maker
17	2212321	Slide, Ice Maker
		Mounting
18	489478	Screw
19	489214	Screw
20	2162085	Light Socket
21	2255743	Light Bulb
22	8281185	Screw
23	2198633	Flipper
24 25	2255558	Cover, Receiver
25	2255562	Slide, Ice Maker Shut Off
26	2255114	P.C. Board,
20	2233114	Receiver
27	2198643	Lens
28	2198589	Light Shield
29	2212340	Light Lens
30	2198641	Bracket, Ice Maker
		Cover
31	2155597	Socket, Light
32		Ladder
	2198609	Left Side
	2198610	Right Side
33	2303234	Shield, Wiring

MOTOR AND ICE CONTAINER PARTS

MOTOR AND ICE CONTAINER PARTS

Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 30 31 30 31 30 31 30 31 30 31 30 31 30 31 30 31 30 31 30 31 30 31 30 31 30 31 30 31 30 31 30 31 31 31 31 31 31 31 31 31 31 31 31 31	2198573 2317254 2317240 2258220 1119007 2317248 2257024 1119005 2257020 2257023 2317239 489229 2257022 489235 2198661 2188918 8281164 3400065 2317262 2198608 8281163 2188919 2317243 2198628 2317250 2188916 2322488 2312580 2212305 489478 2315559 2317251	


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

Illus No.		DESCRIPTION
1		Refrigerator Door
		(Includes Item #6)
	W10169197	White
	W10169199	
	W10169198 W10169200	
	W10169200	Mono Stainless
	W10169201	Mono Satina
2	2256101	Compartment Door
2 3 4	2304235K	Shelf Bin (3)
	3400012	Screw
5	2255411	Clip
6		Door Gasket,
	0004000	Magnetic
	2221302 2221313	Mist Beige Black
	2326338	
7	2156022	Shelf Bin
8		Handle, Extr
	W10127808	•
	W10127810	Biscuit
	W10127809	
	W10127811	Stainless, All
9	W10155511	Screw (4)
10	2182178	Door Closer, Upper Cam
11	489420	Screw
12	400420	Bracket, Door Stop
	2323534	Chrome
	2323534B	Black
13	2301049	
14	2255121	Nameplate
15	1440407040	Handle, Endcap
	W10127813	
	W10127815 W10127814	
	W10127814 W10152864	Stainless, All
	VV 10 102004	Ciannoss, An


FREEZER DOOR PARTS



FREEZER DOOR PARTS

Illus No.		DESCRIPTION
1		Freezer Door (Includes #8
		And Dispenser
		Front Parts)
	W10141323 W10141325	White Biscuit
	W10141323 W10141324	Black
	W10141327	Stainless Steel
	W10177270	Mono Stainless
2	W10177269	Mono Satina
2	W10127808	Handle, Extr White
	W10127810	Biscuit
	W10127809	Black
2	W10127811	Stainless, All
3 4	2255411 W10167528	Clip Dispenser Harness
5	2154473	Connector
6	W10155511	Screw (4)
7		Door Gasket,
	2221303	Magnetic Mist Beige
	2221303	Black
	2326339	Apollo Grey
8	0004040	Thimble-Top
	2301049	For White, Black, Biscuit and
		Stainless VCM
		Models
	2308091	For Stainless
9	2219982	Steel Model Trim, Door Shelf
10	2182179	Door Closer,
		Upper Cam
11	489420	Screw
12	2323534	Bracket, Door Stop Chrome
	2323534B	Black
13	2171157K	Trivet-FC
14	3400012	Screw
15 16	488500	Screw Handle, Endcap
.0	W10127813	White
	W10127815	
	W10127814	Black Stainless All
	W10152864	Stainless, All


DISPENSER FRONT PARTS




DISPENSER FRONT PARTS

Illus No.		DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196537	Screw
3	2194719	Retainer, Levers
4	2304772	Spring, Torsion
5	2196195	Pin
6	2180353	Door, Ice
7	2304355	Door Mechanism Assembly
8 9	2205686	Mechanism Delay Grille, Overflow
•	2206670W	White
	2206670T	Biscuit
	2206670B	Black
	W10171993	Stainless
10	2304317	Water Fitting
		Assembly (Includes
11		Water Tube) Lever, Ice
		Dispenser
	W10152853	White
	W10152855	Biscuit
	W10152854	Black
	W10155161	Apollo Grey
12	2180224	Guide, Ice
13	2180200	Lamp Holder
14 15	2162361 2183771	Switch Bracket, Control
16	3406124	Bulb, Light
17	3400124	Lever, Water
• •		Dispenser
	W10152858	White
	W10152860	Biscuit
	W10152859	Black
40	W10155162	Apollo Grey
18	489000	Screw
19		Front Cover Assembly
	W10157646	White
	W10157648	Biscuit
	W10157647	Black
	W10157650	Stainless,
		Mono Satina (SS)
	W10172006	Mono Stain (NO)
20	625834	Spacer, Switch (2)
21 22	2195051 2304673	Strain Relief
22	2304073	Bracket, Dispenser


AIR FLOW PARTS



CONTROL PARTS




UNIT PARTS



UNIT PARTS

Illus No.	Part No.	DESCRIPTION	Illus No.	. Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3	12825802 W10121484	Insulation, Sound Fan, Blade Condenser Assembly	24	2319825 2317845	Drier Production Service			arts Not Illustrated Parts Not Included
4 5 6		Screw Clip, Condenser Tube, Condenser to Heat Loop	25	2320138	Compressor (Includes Items 12, 13, 17, 18,			Valve, Access (1/4") Valve, Access
7 8		Heat Shield And Drain Pan Tube Suction	26	1115274	19 & 27) (Also Order 876765 Tube Kit) Clip, Wiring			(5/16") Valve, Access (3/8")
9 10 11	2326982 8533993	Control Box	27 28	2304904	Unit Mounting Frame Bracket, Fan Motor			Valve, Access (1/2") Valve, Access
12 13	4387731 2322572	Cover (Service Only) Elec. Control	29 30 31	2323198	Heater, Defrost Clip, Heater		978030	(5/8")
14 15	2223314 2304885	Clip, Retaining Start–Device, Combination	32		Grommet (4) Production		876764	
16		(Start Relay and Overload) Capacitor	33 34 35	489340 2196202		REFF	RIGERA	NT CHARGE
17	2264017 2304899	Unit Cover, Bottom	36 37		Unit Mounting Rail			5.0 oz. (R-134A)
18 19 20	2161324	Evaporator Clip	38 39 40	2161302	Guard, Fan Sleeve Wire Tie			
21 22 23	1105523	Motor, Fan Tray, Evaporator Harness, Unit	41 42 43 63	489427 489478 W10169512 2320322	Screw Clip, Wire & Tube			

ICEMAKER PARTS



ICEMAKER PARTS

IIIu: No		DESCRIPTION
1	489084	Screw
2	2303216	Fitting, Water
		Tube
3	628379	
4	489478	
5	2315534	
6	2208136	Clip, Tube
7	2174358	
8	488649	
9	W10122527	Mold & Heater
		Assembly (Also Order 542638
		Silicone Grease)
10	2304969	
11	627843	
12	2198598	
13	2194712	
14	2315522	
		Thermostat
15	627985	Thermostat (Also
		Order 542369
		Cement
		Alumilastic)
16	8533917	Screw
17	2303583	Bracket, Ice Maker
4.0	400070	Mounting
18	489276	
19		Harness, Wiring
20	626691	Module Assembly
		(Includes Items 21 & 22)
21	626683	,
22	489136	
100	W10122502	Icemaker Assembly

OPTIONAL PARTS (NOT INCLUDED)

For Models: ED5FHAXVQ00, ED5FHAXVT00, ED5FHAXVB00, ED5FHAXVS00, ED5FHAXVY00, ED5FHAXVA00 (White) (Biscuit) (Black) (Stainless Steel) (Mono Satina) (Mono Stainless)

Illus. Part

No. No. DESCRIPTION

PAINT, BULK (1 qt.)

*350942 Primer, White *350939 Black *350930 White *4392901 Biscuit *8171357 Graphite

PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit 72032 Black 80051 Graphite

*Important: The spray paint is not to be used where the paint may make contact with the door gaskets. Illus. Part No. No.

No. DESCRIPTION

PAINT, BULK (1 qt.)

799340 Black 799344 White 4392900 Biscuit 8171358 Graphite

Miscellaneous

8129 Coil Brush 212643 Sealer, Gum (4 Feet) 479502 Tape, Vinyl (3/4 x 108") 505587 Sealer, Mastic (1 Qt.) 503695 Cork, Sealer (1/4 Pound) 542638 Grease, Silicone (1/2 Oz.) 542639 Cement, Alumilastic (1-1/4 Oz.)799833 Kit, Evaporator Repair (Aluminum Epoxy) 833938 Kit, Terminal Connector

Illus. Part

No. No. DESCRIPTION

TORX SCREW WRENCH

1117510 Torx Key